



Switches & Relays



SWITCH, anti-theft alarm, each
E6106 69-E77\$25.00



E5907

SWITCH, back-up lamp, 4sp, each
E5906 64-67\$59.95
E5907 68-78\$59.95



SWITCH, battery disconnect, top post, each
E3826 53-97\$13.95

SWITCH, brake light, each
E5898 68\$53.45



SWITCH, courtesy lamp, each
E5873 55-62\$19.95



SWITCH, courtesy lamp door jamb, each
EC252 63-67 \$7.95



SWITCH, courtesy lamp/key warning door jamb, each
EC253 68-74 \$7.95



SWITCH, door ajar warning, each
E3755 68-72 \$7.95



SWITCH, door ajar /anti theft, each
E4625 73-82 \$3.95



SWITCH, door panel lamp, each
E5875 84-89\$12.49



SWITCH, emergency brake dash light, each
EC306 63-66 \$5.00



E2964



EC435



E2966

SWITCH, glove box lamp, each
E2964 63-67 w/bulb & terminal.... \$12.50
EC435 68-E77 w/bulb & connect.. \$14.95
E2966 78-82 w/bulb & 2 terminals.....\$9.95

RELAY, horn, each
E4129A 74-80 under console\$23.95
E4129B 81-89 under dash\$12.95



E3659



E3660

SWITCH, ignition, each
E3658 55-57\$24.95
E3659 58-59\$64.95
E3660 60-62\$84.95

E5754

E5879



NUT, ignition switch, each
E5754 56-59 \$7.50
E5879 66-67\$12.50

Switches & Relays



SWITCH, mirror, remote control, each
E4048 84-89.....\$27.95



E6218



E2962



E2963



E6180

- SWITCH**, head lamp, each
- E6218 55-57.....\$36.00
 - E6149 55-57.....\$39.95
 - E2962 58-63.....\$36.95
 - E2963 64-67.....\$15.95
 - E6180 68-77.....\$39.95
 - E6181 78-82.....\$39.95




SWITCH, head lamp actuator, each
E6687 63-67.....\$109.00



SWITCH, head lamp door opening, each
E6106 69-77.....\$25.00



SWITCH, head lamp limit, each
E3655 63-67.....\$9.25



SWITCH, head lamp, vacuum override, each
E3774 68-82.....\$14.95



SWITCH, hood open warning, each
E3755 69-74.....\$7.95



SWITCH, power door lock/power window, each
E4047* 86-90.....\$7.00



E4178

SWITCH, power seat adjuster, each
E4046 84-86.....left\$139.95
E4178 92-93.....right\$114.95



E4115



E4118

SWITCH, power window, each
E4115 63-67.....\$50.00
E4118 68-82.....\$24.95



SWITCH, power window/power door lock, each
E4047* 84-90.....\$7.00
*Use with Power Window Switch Bezel #E4062

Switches & Relays



E4132

RELAY, power window, each
 E4090 63-67.....\$32.00
 E4132 68-78.....\$22.95

CIRCUIT BREAKER, power window switch, each
 E4069 67.....\$22.95



CUP, power window switch shield, each
 E4113 63-67.....\$25.00



SWITCH, turn signal, w/harness, each
 E6216 53-62.....\$24.95



SWITCH, turn signal, standard column, each
 E6549 64-66.....\$39.95




FLASHER, turn signal, each
 E4127 69-82.....\$9.95



SWITCH, wiper control, dash, each
 E6157 68-76.....\$49.95



SWITCH, wiper door limit, each
 E6303 68-72.....\$29.00



SWITCH, wiper door vacuum override control under dash, each
 E3774 68-72.....\$14.95



RELAY, wiper, each
 E6305 68-72.....\$59.95



WIRE TERMINAL SET, attaches wires to 68-74 door jamb courtesy lamp, key warning switch, 68-72 door ajar switch and 69-74 hood open switch
 EC789 68-74.....\$7.00